


## Type 6030

2/2-way solenoid valve



## Operating Instructions

## TABLE OF CONTENTS

<b>1</b>	<b>About this document.....</b>	<b>4</b>
1.1	Manufacturer.....	4
1.2	Symbols.....	4
1.3	Terms and abbreviations.....	5
<b>2</b>	<b>Safety.....</b>	<b>6</b>
2.1	Intended use.....	6
2.2	Safety instructions.....	6
<b>3</b>	<b>Product description.....</b>	<b>9</b>
3.1	Product structure.....	9
3.2	Type label.....	10
<b>4</b>	<b>Technical data.....</b>	<b>11</b>
4.1	Standards and directives.....	11
4.2	Operating conditions.....	11
4.3	Circuit function.....	12
<b>5</b>	<b>Installation.....</b>	<b>13</b>
5.1	Preparatory work.....	13
5.2	Installation of push-in flange variant.....	13
5.3	Flange variant installation.....	16
5.4	Installation of socket variants.....	17
5.5	Coil installation.....	17
5.6	Cable plug installation.....	19
<b>6</b>	<b>Electrical connection.....</b>	<b>20</b>
6.1	Cable plug.....	20
6.2	Automotive plugs for IP6K9K coil variants.....	20
<b>7</b>	<b>Faults.....</b>	<b>21</b>
<b>8</b>	<b>Logistics.....</b>	<b>22</b>
8.1	Transport and storage.....	22
8.2	Disposal.....	22

# 1 ABOUT THIS DOCUMENT

The document is an important part of the product and guides the user to safe installation and operation. The information and instructions in this document are binding for the use of the product.

- Before using the product for the first time, read and observe the whole safety chapter.
- Before starting any work on the product, read and observe the respective sections of the document.
- Keep the document available for reference and give it to the next user.
- Contact the Bürkert sales office for any questions.



Further information concerning the product at [country.burkert.com](https://country.burkert.com).

## 1.1 Manufacturer

Bürkert Fluid Control Systems  
Christian-Bürkert-Str. 13–17  
D-74653 Ingelfingen



The contact addresses are available at [country.burkert.com](https://country.burkert.com) in the menu "Contact".

## 1.2 Symbols



### DANGER!

Warns of a danger that leads to death or serious injuries.



### WARNING!

Warns of a danger that can lead to death or serious injuries.



### CAUTION!

Warns of a danger that can lead to minor injuries.

### NOTICE!

Warns of property damage on the product or the installation.



Indicates important additional information, tips and recommendations.



Refers to information in this document or in other documents.

➔ Indicates a step to be carried out.

✓ Indicates a result.

**Menü** Indicates a software user-interface text.

### 1.3 Terms and abbreviations

The terms and abbreviations are used in this document to refer to following definitions.

Device	2/2-way solenoid valve, Type 6030
--------	-----------------------------------



## 2 SAFETY

### 2.1 Intended use

The device is designed to control the flow rate of media. The permitted media are listed in [Technical data](#) [▶ 11].

Prerequisites for safe and trouble-free operation are correct proper transportation, storage, installation, start-up, operation and maintenance.

The instructions are part of the device. The device is intended exclusively for use within the scope of these instructions. Uses of the device that are not described in these instructions, the contractual documents or the type label can lead to severe personal injury or death, damage to the device or property and dangers for the surrounding area or the environment.

- Do not mechanically load the device.
- Only trained and qualified personnel may install, operate and maintain the device. See qualification of persons in [Safety instructions](#) [▶ 6]
- Use the device only in conjunction with third-party devices and components recommended and authorized by Bürkert.
- Use the device only when it is in perfect condition.

### 2.2 Safety instructions

#### Qualification of personnel working with the device

Improper use of the device can lead to serious personal injury or death. To avoid accidents when working with the device, the following minimum requirements must be met:

- Carry out work on the device within the scope of these instructions in a safety-compliant manner.
- Detect and avoid dangers when working on the device.
- Understand the instructions and implement the information contained therein accordingly.

#### Responsibility of the operator

The operator is responsible for observing the location-specific safety regulations, also in relation to personnel.

- Observe the general rules of technology.
- Install the device according to the regulations applicable in the respective country.
- The operator must make hazards arising from the location of the device avoidable by providing appropriate operating instructions.

#### Changes and other modifications, spare parts and accessories

Changes to the device, incorrect installation or use of non-approved devices or components create hazards that can lead to accidents and injuries.

- Do not make any changes to the device.
- Do not mechanically load the device.
- Observe the operating instructions of the device or component used.
- Only use the devices in conjunction with approved devices or components.

Spare parts and accessories that do not meet Bürkert's requirements may impair the operational safety of the device and cause accidents.

→ To ensure operational safety, only use original parts from Bürkert.

#### Operation only after proper transport, storage, installation, start-up or maintenance.

Improper transport, storage, installation, start-up or maintenance endanger the operational safety of the device and can cause accidents. This can lead to serious personal injury or death.

→ Only carry out works which are described in these instructions.

→ Only carry out works using suitable tools.

→ Have all other works carried out by Bürkert only.

#### Technical limit values and media

Non-compliance with technical limit values or unsuitable media can damage the device and lead to leaks. This can cause accidents and seriously injure or kill people.

→ Comply with limit values. See [Technical data \[▶ 11\]](#) and information on the type label.

→ Only feed media into the media ports that are listed in the chapter [Technical data \[▶ 11\]](#).

→ Observe the safety data sheet for the media used.

#### Medium under pressure

Medium under pressure can seriously injure people. In the event of overpressure or pressure surges, the device or lines can burst. Pneumatic lines that are defective or not securely fastened can come loose and swing around.

→ Before working on the device or system, switch off the pressure. Vent or empty the lines.

→ Adhere to the permitted pressure ranges of the medium.

→ Comply with the permitted temperature ranges of the medium.

#### Electric shock due to electrical components

Touching live parts can result in severe electric shock. This can lead to serious personal injury or death.

→ Before working on the device or system, switch off the power supply. Secure it against reactivation.

→ Observe any applicable accident prevention and safety regulations for electrical devices.

#### Hot surfaces and fire hazard

The surface of the device can become hot with fast-switching actuators or with hot media.

→ Wear suitable protective gloves.

→ Keep highly flammable substances and media away from the device.

#### Working on the device

Working on the device that has not been powered down, unauthorised switching on or uncontrolled start-up of the system can cause accidents. This can lead to serious personal injury or death.

→ Only work on the device when it is not in use.

→ Ensure that the device or system cannot be switched on unintentionally.

→ Only start the process in a controlled manner following disruptions. Observe sequence:

1. Apply supply voltage or pneumatic supply.
2. Charge the device with medium.

**Risk of injury from malfunctioning valves with alternating current (AC)**

If the core sticks, the solenoid will overheat and cause the valve to malfunction.

→ Monitor valve function.



### 3 PRODUCT DESCRIPTION

Type 6030 is a compact 2/2-way solenoid valve with the following properties:

- Vibration-proof, screwed coil system.
- Increased leak proofing through welded core guide tube.
- Available as a flange or push-in flange variant for fast system integration.
- Degree of protection IP65 or IP6K9K with automotive plug.
- Optimised for use in hydrogen applications, such as fuel cells or electrolysis.

#### 3.1 Product structure




Fig. 1: Type 6030 Push-in flange variant FC22/FC23

1	Coil	2	Retaining plate
3	Valve body	4	Type label
5	Nut for coil attachment		




Fig. 2: Type 6030 flange variant FK18/FK19

1	Coil	2	Valve body
3	Type label	4	Nut for coil attachment




Fig. 3: Type 6030 socket variants GM81/GM82

1	Coil	2	Valve body
3	Type label	4	Nut for coil attachment

### 3.2 Type label




Fig. 4: Type 6030 type label (example)

1	Type	2	Circuit function
3	Orifice	4	Sealing material
5	Body material	6	Operating pressure
7	Cold power (tolerance $\pm 10\%$ )	8	Duty cycle
9	CE marking	10	Manufacture code
11	Barcode	12	Article number
13	Serial number	14	Ambient temperature
15	Operating voltage	16	Port connection

## 4 TECHNICAL DATA

### 4.1 Standards and directives

The device complies with the valid EU harmonisation legislation.

The harmonised standards that have been applied for the conformity assessment procedure are listed in the current version of the EU Declaration of Conformity.

### 4.2 Operating conditions

Medium	neutral gases and liquids, optimised for hydrogen
Medium temperature	-40...+110 °C
Ambient temperature	-40...+55 °C/+75 °C for stationary applications
	-40...+85 °C for mobile applications
Storage temperature	-40...+80 °C
Operating mode	Unless otherwise specified on the type label, the solenoid actuator is suitable for continuous operation.
	Power must be reduced to max. 25% of the nominal power (holding phase) with the aid of current control or PWM signal after max. 200 ms (switch-on pulse) for mobile applications with increased ambient temperature (max. +85 °C).
Installation position	Any, preferably actuator face up
Protection classes (according to VDE 0580)	I (standard coil)
	III (coil with automotive plug)
Degree of protection (EN 60529 / IEC 60529)	IP65*
	<i>*With correctly connected cable plug.</i>
Degree of protection (ISO 20653)	IP6K, IPX7 (immersion test in accordance with ISO 16750-4), IPX9K*
	<i>*If a coil is used with an automotive plug. Degree of protection can only be guaranteed if the coil is not removed from the valve.</i>
Materials	see data sheet

#### Temperatures for valves with UL/UR approval

Medium	Seal material	V code	Medium temperature	Ambient temperature
Air, inert gas, vapour, water, hydrogen	EPDM + EPDM (AA)	-	-40 °C...+110 °C	-40 °C...+75 °C


Tab. 1: Temperatures for valves with UL/UR approval

### NOTICE!

#### High pressure surges

Liquids and high differential pressure may cause high pressure surges.

### 4.3 Circuit function

Icon	Description
	<p>Circuit function A (CF A), NC 2/2-way solenoid valve, direct-acting Normally closed</p>

Tab. 2: Circuit function



## 5 INSTALLATION



Risk of injury or material damage when working on the device or system.

→ Read and observe the chapter [Safety \[▶ 6\]](#) before working on the device or system.

### 5.1 Preparatory work



#### **DANGER!**

Risk of injury from high pressure and discharge of medium.

→ Before working on the device or system, switch off the pressure. Vent or drain lines.

- Devices that are suitable for use with food according to the manufacturer should be flushed for 5 minutes prior to start-up.
- Clear pipes of any dirt.
- Seal pipe connections using an elastomer seal or PTFE tape. Ensure that seal material does not get into the device.
- Fit a dirt trap on a dirty medium before the valve inlet (mesh size 0.2...0.4 mm).

### 5.2 Installation of push-in flange variant




Fig. 5: Installation of the push-in flange variant

- Ensure that the O-rings on the valve body and the seal surfaces of the connection housing are free of any damage.
- Press the valve into the connection housing.
- Tightly screw in the retaining plate, observing the tightening torque indicated in the following table.

**NOTICE!**

→ Ensure that the O-rings on the valve body and the seal surfaces of the connection housing are not damaged during installation.

Variant	Nominal diameter DN	Tightening torques [Nm]	Screw
FC22	1...3	3	M4 x 15 A2 8.8 (screws not included in the scope of delivery)
FC23	4...6	3	M4 x 15 A2 8.8 (screws not included in the scope of delivery)

Tab. 3: Push-in flange variant

**NOTICE!**

**Please note screw depth**

Depending on the screw depth of the mating block, longer screws than the specified size can also be used.

- Use only suitable screws.
- Please note the maximum screw depth of the mating block.
- Observe the tightening torque value.
- Contact Bürkert service if you have any questions.




Fig. 6: Connection diagram 1 for plug-in flange variant FC22

MAN 1000626822 EN Version: A Status: RL (released | freigegeben) printed: 18.10.2024




Fig. 7: Connection diagram 2 for plug-in flange variant FC22




Fig. 8: Connection diagram 1 for plug-in flange variant FC23




Fig. 9: Connection diagram 2 for plug-in flange variant FC23

### 5.3 Flange variant installation




Fig. 10: Flange variant installation

- Ensure that the O-rings on the valve body and the seal surfaces of the connection housing are free of any damage.
- Place the valve on the connection housing.
- Tightly screw in the valve body, observing the tightening torque indicated in the following table.

#### NOTICE!

- Ensure that the O-rings on the valve body and the seal surfaces of the connection housing are not damaged during installation.

Variant	Nominal diameter DN	Tightening torque [Nm]	Screw
FK18	1...3	3	M4 x 20 A2 8.8 (screws not included in the scope of delivery)
FK19	4...6	3	M4 x 20 A2 8.8 (screws not included in the scope of delivery)

Tab. 4: Flange variant




Fig. 11: Connection diagram for flange variant FK18 and FK19

## 5.4 Installation of socket variants




Fig. 12: Installation of socket variants

- Note the flow direction: from 1 to 2 (from P to A).
- Ensure that the seal surfaces on the port connections are free of any damage.
- Hold the device on the valve body using an open-end wrench and screw into the pipe.

### NOTICE!

- Be sure not to damage the seal surfaces on the port connections when screwing into the pipe.

## 5.5 Coil installation

### **! WARNING!**

Risk of injury due to medium leak

Medium may leak if a firmly fastened nut is loosened.

- Do not continue to rotate firmly fastened nuts.

**! CAUTION!**

**Risk of injury from electric shock**

If there is no protective conductor function between the coil and the body, there is a risk of electric shock.

- The anti-twist device (plastic ring) must be inserted into the body pins during installation. It must not protrude over the octagonal nipple.
- Check the protective conductor function after installing the coil.

**NOTICE!**

**Overheating of coil, fire hazard**

Connecting the coil without a pre-installed valve will cause overheating and destroy the coil.

- Only connect the coil after the valve has been installed.



**Guarantee of the degree of protection**

When using a coil with an automotive connector, the degree of protection can only be guaranteed if the coil is not removed from the valve.




Fig. 13: Coil installation

1	Nut	2	O-ring
3	Armature		

- Check the correct positioning of the O-ring on the valve body.
- Slide the coil onto the core guide tube. Make sure that the anti-twist device is fully inserted into the body spigot. It must not protrude axially over the octagonal nipple.
- Fasten the nut with an open-end wrench. When screwing in, observe the tightening torque indicated in the following table.
- Check protective conductor function.

Variant	Nominal diameter DN	Tightening torque [Nm]
all variants	1...3	2.8
	4...6	5

Tab. 5: Coil installation

## 5.6 Cable plug installation

### **!** CAUTION!

If there is no protective conductor function, there is a risk of injury from electric shock.

- Always connect the protective conductor.
- Check electrical continuity between coil and body.




Fig. 14: Install the cable plug

1	Seal
---	------

- Attach the cable plug (for permitted types, see data sheet) to the contacts on the coil.
- Check that the seal is properly fitted.
- Tightly screw cable plug, while observing a tightening torque of 0.3 Nm (AC08) or 1 Nm (AC10).
- Connect the protective conductor.
- Check electrical continuity between coil and body.

## 6 ELECTRICAL CONNECTION

### **WARNING!**

Risk of injury from electric shock.

- Switch off the power supply before working on the device or system. Secure it against reactivation.
- Observe the applicable accident prevention and safety regulations for electrical devices.

### 6.1 Cable plug



Permitted variants of the cable plug and further information such as wiring and electrical characteristics are available in the data sheet for Type 6030 at [country.burkert.com](http://country.burkert.com).

### 6.2 Automotive plugs for IP6K9K coil variants

For mobile applications, coils are provided with the following automotive plugs:

- KOSTAL MLK1.2 plug, 2-pin, A-coded (male)
- TE MCON 1.2 plug, 2-pin, A-coded (male)



Fig. 15: Automotive plugs for IP6K9K coil variants AC10

## 7 FAULTS



Risk of injury or material damage when working on the device or system.

→ Read and observe the chapter [Safety \[▶ 6\]](#) before working on the device or system.



### **DANGER!**

Risk of injury from high pressure and discharge of medium.

→ Before working on the device or system, switch off the pressure. Vent or drain lines.



### **WARNING!**

Risk of injury from electric shock.

→ Switch off the power supply before working on the device or system. Secure it against reactivation.

→ Observe the applicable accident prevention and safety regulations for electrical devices.

If faults occur, check whether

- the device has been installed according to regulations
- the connection has been properly made
- the device has been damaged
- all screws have been tightened
- voltage and pressure have been applied
- the pipes are clean

Valve does not actuate

Possible cause:

- Short circuit or coil interrupted
- Core or core area contaminated
- Medium pressure outside the permitted pressure range
- Manual override locked

Valve does not close

Possible cause:

- Interior of the valve soiled
- Manual override locked

## 8 LOGISTICS

### 8.1 Transport and storage

- Protect the device against moisture and dirt in the original packaging during transportation and storage.
- Avoid UV radiation and direct sunlight.
- Protect connections from damage with protective caps.
- Observe permitted storage temperature.

### 8.2 Disposal

Environmentally friendly disposal



- Follow national regulations regarding disposal and the environment.
- Collect electrical and electronic devices separately and dispose of them as special waste.

**FLU-TECH CO. LTD.**



**Email:** sales@flutech.co.th **Website:** <https://flutech.co.th>

**Tel:** 02-384-6060, 086-369-5871-3 **Fax:** 02-384-5701 **LINE OA:** @flutech.co.th

**Address (HQ):** 845/3-4, Moo 3, Theparak Rd., T. Theparak, A. Mueang Samut Prakan, Samut Prakan, 10270,Thailand