



Armatures for analysis sensors

- For many different types of installations and applications
- Large range of sensor holders
- General purpose and pharmaceutical applications, water treatment, food & beverage industry

Product variants described in the data sheet may differ from the product presentation and description.

Can be combined with

	Type 8203 pH- and ORP-probes	▶
	Type 8221 Conductivity sensor for hygienic applications	▶
	Type 8232 Chlorine sensor	▶
	Type S020 Insertion fitting for flow or analysis measurement	▶
	Type BBS-25 Clamp socket, clamps and seals according to DIN 32676	▶

Type description

The holder range allows the installation of 120 mm analysis probes (pH/redox potential (ORP)/conductivity) or chlorine sensors, etc., on tanks or process pipelines and covers general purpose, water treatment, food & beverage and pharmaceutical applications.

This product range includes a variety of process connections for general purpose, hygienic holders and transparent one-piece holders for multiple measurements. The general holders are available with or without protective rods. The hygienic variants are also available with or without protection rods or tubes and can be directly welded on, as well as used for a 2" (DN 50/40) connection, suitable for VARINLINE process connections from GEA Tuchenhausen. The special transparent, one-piece holders (so-called analysis measurement chambers) can hold from one to several probes and sensors, depending on the design.

Depending on the variant, the holder can be used for steam sterilisation, autoclaving, cleaning in place (CIP), to save space, for positioning the sensor according to the flow of the medium, or for mounting it in vertical pipes, but can also be equipped with a Pt1000 temperature sensor.

Analysis measurement chambers are available for specific integration into the process. Transparent, they allow visualization of the fluid flow and ensure optimal measuring conditions. The single-slot analysis measurement chamber has been designed for use with the Type 8232 chlorine sensor; those with three or four slots allow the simultaneous measurement of several parameters (chlorine, temperature and pH/ORP/conductivity). Two of the slots are always intended for temperature and chlorine sensors, the others are intended for other analysis probes. The three-slot analysis measurement chamber is available in cold or warm water variant.

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

FLU-TECH CO. LTD.

Email: sales@flutech.co.th **Website:** https://flutech.co.th

Tel: 02-384-6060, 086-369-5871-3 **Fax:** 02-384-5701 **LINE OA:** @flutech.co.th

Address (HQ): 845/3-4, Moo 3, Theparak Rd., T. Theparak, A. Mueang Samut Prakan, Samut Prakan, 10270, Thailand



Table of contents

1. General technical data	4
1.1. About the device	4
1.2. All variants.....	4
2. Product variants	5
2.1. General purpose holder	5
G 2" connection	5
G 1" or solvent union connection	5
2.2. Hygienic purpose holder	5
G 1¼" connection (28 or 46 mm O-ring position).....	5
1½" clamp (Ø 50.5 mm) connection, short immersion depth.....	6
1½" clamp (Ø 50.5 mm) connection, long immersion depth	6
2" (DN 50/40) connection adapted for GEA Tuchenhausen VARINLINE process connections.....	6
Direct welding connection	7
2.3. Analysis measurement chamber.....	7
With one sensor slot for chlorine measurement	7
With three sensor slots for chlorine, temperature and one other analysis measurements	8
With four sensor slots for chlorine, temperature and two other analysis measurements.....	8
3. Approvals and conformities	9
3.1. General notes.....	9
3.2. Conformity	9
3.3. Standards.....	9
3.4. Pressure Equipment Directive (PED).....	9
Device used on a pipe	9
Device used on a vessel	9
3.5. Foods and beverages/Hygiene	10
4. Materials	10
4.1. Bürkert resistApp	10
5. Dimensions	11
5.1. General purpose holder	11
G 2" connection	11
G 1" connection	12
Solvent union connection	12
5.2. Hygienic holder.....	13
G 1¼" connection (28 or 46 mm O-ring position).....	13
1½" clamp connection (Ø 50.5 mm), short immersion depth.....	13
1½" clamp connection (Ø 50.5 mm), long immersion depth	14
2" (DN 50/40) connection adapted for GEA Tuchenhausen VARINLINE process connections.....	14
Direct welding connection	15
5.3. Analysis measurement chamber.....	15
With one sensor slot for chlorine measurement	15
With three sensor slots for chlorine, temperature and one other analysis measurements	16
With four sensor slots for chlorine, temperature and two other analysis measurements.....	17
6. Product installation	18
6.1. Installation notes.....	18
General purpose holder with G 2" connection for installation on Type S020 Bürkert fitting	18
General purpose holder with G 1" or solvent connection for installation on T-fitting	18
Hygienic holder with G 1¼" connection and O-ring position of 28 or 46 mm for installation on sockets.....	18
Hygienic holder, direct welding for installation on pipe	19

Analysis measurement chamber20

7. Networking and combination with other Bürkert products 23

7.1. Combination of general purpose holder with G 2" connection for installation on S020 Bürkert fitting.....23
 7.2. Combination with available Type S020 Insertion fittings DN23
 7.3. Combination of general purpose with G 1", solvent connection or hygienic holders.....24
 7.4. Combination of the analysis measurement chamber25

8. Ordering information 26

8.1. Bürkert eShop26
 8.2. Recommendation regarding product selection.....26
 General purpose or hygienic holders for pH/ORP/conductivity measurement for tank or pipe installation26
 Analysis measurement chamber26
 8.3. Bürkert product filter27
 8.4. Ordering chart27
 General purpose or hygienic holders for pH/ORP/conductivity measurement for tank or pipe installation27
 Analysis measurement chamber28
 8.5. Ordering chart accessories28

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024



1. General technical data

1.1. About the device

These holders are used in combination with 120 mm analysis probes for general or hygienic purposes. These must be equipped with either a Bürkert pH- or ORP-probe Type 8203 or a conductivity probe Type 8221. The special analysis measurement chamber must be used with the chlorine sensor Type 8232.

See [data sheet Type 8203](#) ▶, [data sheet Type 8221](#) ▶ or [data sheet Type 8232](#) ▶ for more information.

1.2. All variants

Product properties

Material

Make sure the device materials are compatible with the fluid you are using.
Further information can be found in chapter [“4.1. Bürkert resistApp” on page 10](#).

Depending on the holder version.
Further information on the materials can be found in chapter [“2. Product variants” on page 5](#).

Medium data

Fluid temperature	Depending on the holder version Further information can be found in chapter “2. Product variants” on page 5 . Temperature limits may depend on the inserted probe. Refer to the relevant operating instructions and data sheet of the probe. If the temperature ranges given for the holder and the inserted probe are different, use the most restrictive range.
Fluid pressure	Depending on the holder version Further information can be found in chapter “2. Product variants” on page 5 . Pressure limits may depend on the inserted probe. Refer to the relevant operating instructions and data sheet of the probe. If the pressure ranges given for the holder and the inserted probe are different, use the most restrictive range.

Process/Pipe connection & communication

Process connection	<ul style="list-style-type: none"> • General purpose holder <ul style="list-style-type: none"> – G 2" for use with Type S020 Insertion fitting – G 1" for use with T-fitting – Solvent union for use with T-fitting d32 x d32 up to d32 x d110 • Hygienic holder <ul style="list-style-type: none"> – G 1¼" (28 or 46 mm O-ring position) – Clamp 1½" (Ø 50.5 mm) – 2" (DN 50/40) connection adapted for GEA Tuchenhausen VARINLINE process connections – Direct welding on pipe • Analysis measurement chamber <ul style="list-style-type: none"> – Straight ¼" screw-in connections for hose 6/8 (for inlet and outlet) with O-ring, mounting nut (to fasten the sensor) and hose sleeve (to sample)
--------------------	--

Approvals and conformities

Directives

Pressure equipment directive	Complying with article 4, paragraph 1 of 2014/68/EU directive Further information on the pressure equipment directive can be found in chapter “3.4. Pressure Equipment Directive (PED)” on page 9 .
------------------------------	--

Environment and installation

Ambient temperature	Temperature limits may depend on the inserted probe. Further information can be found in the relevant operating instructions and data sheet of the probe.
---------------------	--

2. Product variants

2.1. General purpose holder

G 2" connection



This holder is always equipped with protection rods, and is available with or without boring for a Pt1000 temperature probe/liquid earth rod. It is designed for use with Insertion fitting, Type S020. Further information can be found in the [data sheet Type S020](#) ▶.

Product properties	
Material	<ul style="list-style-type: none"> Body in PVC or stainless steel (316L/1.4404) Seal in FKM (EPDM optional)
Dimensions	Further information can be found in chapter " G 2" connection " on page 11.
Medium data	
Fluid temperature	With Type S020 fitting in: <ul style="list-style-type: none"> PVC: 0...+50 °C (+32...+122 °F) Stainless steel: -20...+130 °C (+5...+266 °F)
Fluid pressure.	With Type S020 fitting in: <ul style="list-style-type: none"> PVC: max. PN 10 (145 PSI) Stainless steel: max. PN 16 (232 PSI)

G 1" or solvent union connection



This holder has no protection rod, but is available with or without boring for a Pt1000 temperature probe/liquid earth rod.

Product properties	
Material	<ul style="list-style-type: none"> Body in PVC Seal in FKM
Dimensions	Further information can be found in chapter " G 1" connection " on page 12 or " Solvent union connection " on page 12.
Medium data	
Fluid temperature	0...+50 °C (+32...+176 °F)
Fluid pressure	Max. PN 10 (145 PSI)

2.2. Hygienic purpose holder

G 1¼" connection (28 or 46 mm O-ring position)



This support, equipped with 3 rods ensuring a good protection of the sensor, allows an easy cleaning. Thanks to its sanitary design, steam sterilisation, autoclaving and CIP cleaning are possible.

Product properties	
Material	<ul style="list-style-type: none"> Body in stainless steel (316L/1.4435) (316Ti/1.4571 on request) Seal in EPDM (FKM or PTFE on request)
Surface quality	Ra<0.4 µm (15 µin.) electro-polished
Dimensions	Further information can be found in chapter " G 1¼" connection (28 or 46 mm O-ring position) " on page 13.
Medium data	
Fluid temperature	-10...+135 °C (+14...+275 °F)
Fluid pressure	Max. 6 bar (87 PSI)
Approvals and conformities	
Foods and beverages/ Hygiene	<ul style="list-style-type: none"> USP class VI declaration FDA declaration of conformity
Materials	<ul style="list-style-type: none"> Inspection certificate 3.1 On request: certification of conformity for the surface quality

1½" clamp (Ø 50.5 mm) connection, short immersion depth



This support, equipped with 3 rods ensuring a good protection of the sensor, allows an easy cleaning. Thanks to its sanitary design, steam sterilisation, autoclaving and CIP cleaning are possible.

Product properties	
Material	<ul style="list-style-type: none"> • Body in stainless steel (316L/1.4435) • Seal in EPDM
Surface quality	Ra < 0.4 µm (15 µin.) electro-polished
Dimensions	Further information can be found in chapter "1½" clamp connection (Ø 50.5 mm), short immersion depth" on page 13.
Medium data	
Fluid temperature	- 10...+ 135 °C (+ 14...+ 275 °F)
Fluid pressure	Max. 6 bar (87 PSI)
Approvals and conformities	
Foods and beverages/ Hygiene	<ul style="list-style-type: none"> • USP class VI declaration • FDA declaration of conformity • ECR1935/2004 declaration
Materials	<ul style="list-style-type: none"> • Inspection certificate 3.1 • On request: certification of conformity for the surface quality

1½" clamp (Ø 50.5 mm) connection, long immersion depth



This support, equipped with a tube ensuring a good protection of the sensor, allows an easy cleaning. Thanks to its sanitary design, steam sterilisation, autoclaving and CIP cleaning are possible.

Product properties	
Material	<ul style="list-style-type: none"> • Body in stainless steel (316L/1.4404) • Seal in FKM
Surface quality	Ra < 1.6 µm (63 µin.)
Dimensions	Further information can be found in chapter "1½" clamp connection (Ø 50.5 mm), long immersion depth" on page 14.
Medium data	
Fluid temperature	- 10...+ 135 °C (+ 14...+ 275 °F)
Fluid pressure	Max. 6 bar (87 PSI)

2" (DN 50/40) connection adapted for GEA Tuchenhagen VARINLINE process connections



This 15° variant support enables the probe to be positioned in relation to the flow direction or to be mounted in vertical pipes.

Product properties	
Material	<ul style="list-style-type: none"> • Body in stainless steel (316L/1.4435) • Seal in EPDM
Surface quality	Ra < 0.4 µm (15 µin.)
Dimensions	Further information can be found in chapter "2" (DN 50/40) connection adapted for GEA Tuchenhagen VARINLINE process connections" on page 14.
Medium data	
Fluid temperature	- 10...+ 135 °C (+ 14...+ 275 °F)
Fluid pressure	Max. 6 bar (87 PSI)
Approvals and conformities	
Foods and beverages/ Hygiene	<ul style="list-style-type: none"> • USP class VI declaration • FDA declaration of conformity • ECR1935/2004 declaration
Materials	<ul style="list-style-type: none"> • Inspection certificate 3.1 • On request: certification of conformity for the surface quality

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

Direct welding connection



This support saves space and is designed for installation in fermenters and many other applications on tanks and pipelines. Steam sterilisation, autoclavation, CIP are possible.

Product properties	
Material	<ul style="list-style-type: none"> • Body in stainless steel (316L/1.4435) • Seal in EPDM
Surface quality	Ra < 0.4 µm (15 µin.)
Dimensions	Further information can be found in chapter “Direct welding connection” on page 15.
Medium data	
Fluid temperature	- 10...+ 145 °C (+ 14...+ 284 °F)
Fluid pressure	Max. 16 bar (232 PSI)
Approvals and conformities	
Foods and beverages/ Hygiene	<ul style="list-style-type: none"> • USP class VI declaration • FDA declaration of conformity • ECR1935/2004 declaration
Materials	<ul style="list-style-type: none"> • Inspection certificate 3.1

2.3. Analysis measurement chamber

With one sensor slot for chlorine measurement



This holder is designed for use with the chlorine sensor, Type 8232.
Further information can be found in the **data sheet Type 8232** ▶.

Product properties	
Material	<ul style="list-style-type: none"> • Body in PMMA polished, bevelled edges • Mounting union nut in PVC grey • O-ring holder in PVC grey • Slide ring (30×25.5×4) in PETP black • Hose connection in PA grey • Inlet needle valve with knurling in PVC grey • Float in PEEK nature • M10 sealing plug in PVC grey • Sample needle valve with knurling in PVC grey • Seal: <ul style="list-style-type: none"> – O-ring (30×2.6) in FPM – O-ring (25×2.5) in Silicone – O-ring (12.42×1.78) in NBR
Dimensions	PMMA block: D 50×W 80×H 175 mm Further information can be found in chapter “With one sensor slot for chlorine measurement” on page 15.
Medium data	
Fluid flow rate	> 15 l/h (sample)
Fluid temperature	Max. 45 °C (max. 113 °F) Permitted operating temperature of the sensor has to be respected.
Fluid pressure	Max. 4 bar (58 PSI) Permitted operating pressure of the sensor has to be respected.

With three sensor slots for chlorine, temperature and one other analysis measurements



This holder is designed for the installation of a chlorine sensor Type 8232, a temperature sensor (see chapter “8.5. Ordering chart accessories” on page 28) and one electrochemical electrode with a PG13.5 threaded connection (pH or redox from Type 8203, conductivity from Type 8221). Further information can be found in the data sheets Type 8232 ▶, Type 8203 ▶ and Type 8221 ▶.

Product properties	
Material	<ul style="list-style-type: none"> • Body in PMMA polished • Variant cold water: connection in PP, screw connection in PVC • Variant warm water: connection in PVDF, screw connection in PVDF
Dimensions	PMMA block: D 50xW 140xH 130 mm Further information can be found in chapter “With three sensor slots for chlorine, temperature and one other analysis measurements” on page 16.
Medium data	
Fluid flow rate	> 30 l/h (sample)
Fluid temperature	<ul style="list-style-type: none"> • Cold water variant: max. 50 °C (max. 122 °F) • Warm water variant: max. 80 °C (max. 176 °F) Permitted operating temperature of the sensor has to be respected.
Fluid pressure	<ul style="list-style-type: none"> • Cold water variant: max. 6 bar (87 PSI) • Warm water variant: max. 8 bar (116 PSI) Permitted operating pressure of the sensor has to be respected.

With four sensor slots for chlorine, temperature and two other analysis measurements



This holder is designed for the installation of a chlorine sensor Type 8232, a temperature sensor (see chapter “8.5. Ordering chart accessories” on page 28) and two electrochemical electrodes with a PG13.5 threaded connection (pH or redox from Type 8203, conductivity from Type 8221). Further information can be found in the data sheets Type 8232 ▶, Type 8203 ▶ and Type 8221 ▶.

Product properties	
Material	<ul style="list-style-type: none"> • Body in PMMA polished • Connection in PVDF, screw connection in PVDF
Dimensions	PMMA block: D 60xW 140xH 135 mm Further information can be found in chapter “With four sensor slots for chlorine, temperature and two other analysis measurements” on page 17.
Medium data	
Fluid flow rate	> 30 l/h (sample)
Fluid temperature	Max. 80 °C (max. 176 °F) Permitted operating temperature of the sensor has to be respected.
Fluid pressure	Max. 8 bar (116 PSI) Permitted operating pressure of the sensor has to be respected.

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

3. Approvals and conformities

3.1. General notes

- The approvals and conformities listed below must be stated when making enquiries. This is the only way to ensure that the product complies with all required specifications.
- Not all available variants of the device can be supplied with the below mentioned approvals or conformities.

3.2. Conformity

In accordance with the Declaration of Conformity, the product is compliant with the EU Directives.

3.3. Standards

The applied standards which are used to demonstrate compliance with the EU Directives are listed in the EU-Type Examination Certificate and/or the EU Declaration of Conformity.

3.4. Pressure Equipment Directive (PED)

The device conforms to article 4, paragraph 1 of the Pressure Equipment Directive (PED) 2014/68/EU under the following conditions:

Device used on a pipe

Note:

- The data in the table is independent of the chemical compatibility of the material and the fluid.
- PS = maximum admissible pressure (in bar), DN = nominal diameter of the pipe

Type of fluid	Conditions
Fluid group 1, article 4, paragraph 1.c.i	DN ≤ 25
Fluid group 2, article 4, paragraph 1.c.i	DN ≤ 32 or PS*DN ≤ 1000
Fluid group 1, article 4, paragraph 1.c.ii	DN ≤ 25 or PS*DN ≤ 2000
Fluid group 2, article 4, paragraph 1.c.ii	DN ≤ 200 or PS ≤ 10 or PS*DN ≤ 5000

Device used on a vessel

Note:

- The data in the table is independent of the chemical compatibility of the material and the fluid.
- PS = maximum admissible pressure, V = vessel volume

Type of fluid	Conditions
Fluid group 1, article 4, paragraph 1.a.i	V > 1 L and PS*V ≤ 25 bar.L or PS ≤ 200 bar
Fluid group 2, article 4, paragraph 1.a.i	V > 1 L and PS*V ≤ 50 bar.L or PS ≤ 1000 bar
Fluid group 1, article 4, paragraph 1.a.ii	V > 1 L and PS*V ≤ 200 bar.L or PS ≤ 500 bar
Fluid group 2, article 4, 1.a.ii	PS > 10 bar and PS*V ≤ 10000 bar.L or PS ≤ 1000 bar


DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

3.5. Foods and beverages/Hygiene

Conformity	Description
FDA	FDA – Code of Federal Regulations The variants with the housing made of stainless steel (316L/1.4435) materials and the seal made of EPDM materials comply in their composition with the Code of Federal Regulations published by the FDA (Food and Drug Administration, USA) according to the manufacturer’s declaration.
USP	United States Pharmacopeial Convention (USP) The variants with the housing made of stainless steel (316L/1.4435) materials and the seal made of EPDM materials are biocompatible according to USP or ISO according to the manufacturer’s declaration.
	EC Regulation 1935/2004 of the European Parliament and of the Council All wetted materials are compliant with EC Regulation 1935/2004 according to the manufacturer’s declaration.

4. Materials

4.1. Bürkert resistApp



Bürkert resistApp – Chemical resistance chart

You want to ensure the reliability and durability of the materials in your individual application case? Verify your combination of media and materials on our website or in our resistApp.

[Start chemical resistance check](#)


5. Dimensions

5.1. General purpose holder

G 2" connection

Note:

- Dimensions in mm, unless otherwise stated
- With analysis probe and Pt1000 temperature probe/liquid earth rod (must be ordered separately)
- For installation on Bürkert Type S020 fitting made of PVC or stainless steel




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

G 1" connection

Note:


- Dimensions in mm, unless otherwise stated
- With analysis probe and Pt1000 temperature probe/liquid earth rod (must be ordered separately)
- For installation on T-fitting made of PVC



Solvent union connection

Note:

- Dimensions in mm, unless otherwise stated
- With analysis probe and Pt1000 temperature probe/liquid earth rod (must be ordered separately)
- For installation on T-fitting made of PVC




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

5.2. Hygienic holder

G 1 1/4" connection (28 or 46 mm O-ring position)

Note:


- Dimensions in mm, unless otherwise stated
- With analysis probe (must be ordered separately)
- To install in weld-in socket 15°, see chapter "8.5. Ordering chart accessories" on page 28 and data sheet Type BBS-11 ▶



1 1/2" clamp connection (Ø 50.5 mm), short immersion depth

Note:

- Dimensions in mm, unless otherwise stated
- With analysis probe (must be ordered separately)




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

1½" clamp connection (Ø 50.5 mm), long immersion depth

Note:


- Dimensions in mm, unless otherwise stated
- With analysis probe and Pt1000 temperature probe/liquid earth rod (must be ordered separately)



2" (DN 50/40) connection adapted for GEA Tuchenhagen VARINLINE process connections

Note:

- Dimensions in mm, unless otherwise stated
- With analysis probe (must be ordered separately)




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

Direct welding connection

Note:

Dimensions in mm, unless otherwise stated




5.3. Analysis measurement chamber

With one sensor slot for chlorine measurement

Note:

Dimensions in mm, unless otherwise stated




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

With three sensor slots for chlorine, temperature and one other analysis measurements

Note:

Dimensions in mm, unless otherwise stated




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

With four sensor slots for chlorine, temperature and two other analysis measurements

Note:

Dimensions in mm, unless otherwise stated



DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

6. Product installation

6.1. Installation notes

General purpose holder with G 2" connection for installation on Type S020 Bürkert fitting

A complete pH/ORP/conductivity sensor consists of the following components:

Installation example	No.	Description
	1	A complete probe holder Type 8200 with nut and seals
	2	A pH/ORP probe Type 8203 or a conductivity probe Type 8221 of 120 mm with PG13.5 connection See data sheet Type 8203 ▶ or data sheet Type 8221 ▶
	3	A Pt1000 temperature probe/liquid earth rod (optional, if needed) Further information can be found in chapter “8.5. Ordering chart accessories” on page 28 .
	4	An Type S020 Bürkert fitting (G 2" connection) See data sheet Type S020 ▶

General purpose holder with G 1" or solvent connection for installation on T-fitting

A complete pH/ORP/conductivity sensor consists of the following components:

Installation example	No.	Description
	1	A probe holder Type 8200 with external thread G 1" process connection or solvent union process connection
	2	A pH/ORP probe Type 8203 or conductivity probe Type 8221 of 120 mm with PG13.5 connection See data sheet Type 8203 ▶ or data sheet Type 8221 ▶
	3	A Pt1000 temperature probe/liquid earth rod (optional, if needed) Further information can be found in chapter “8.5. Ordering chart accessories” on page 28 .
	4	A T-fitting (with internal thread G 1" connection or solvent union Ø 32 mm connection to the probe holder)

Hygienic holder with G 1¼" connection and O-ring position of 28 or 46 mm for installation on sockets

A complete pH/ORP/conductivity sensor consists of the following components:

Installation example	No.	Description
	1	A G 1¼" probes holder Type 8200 with O-ring position of 28 mm or 46 mm
	2	A pH/ORP probe Type 8203 or conductivity probe Type 8221 of 120 mm with PG13.5 connection See data sheet Type 8203 ▶ or data sheet Type 8221 ▶
	3	A Type BBS-11 weld-in socket with 15° (sockets 15°) which are welded on pipes or tanks The sockets have a safety construction. The socket seals only if the O-ring of the holder is exactly in the right position. Otherwise the fluid leaks through the G 1¼" coupling nut. Further information on socket ordering can be found in chapter “8.5. Ordering chart accessories” on page 28 or see data sheet Type BBS-11 ▶.

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

Hygienic holder, direct welding for installation on pipe

The probe's steel mantle holder can be welded into a designated hole on the tank wall with almost any installation depth. As a result the probe is always immersed to exactly the desired position in the tank.
 The O-ring can be easily replaced thanks to the "seal pusher" part (see following description).

A complete pH/ORP/conductivity sensor consists of the following components:

Installation example	No.	Description
	<p>1 A probe holder Type 8200 made of</p> <ol style="list-style-type: none"> a "steel sleeve" which must be welded into a circular cut-out of appropriate size (28 mm diameter) at its place of use. Installation depth can be 0...55 mm. a "seal frame" which is inserted into the steel sleeve (after having checked that all o-rings are in place in their appropriate grooves, and are free of damage). 	
	<p>2</p> <ul style="list-style-type: none"> A pH/ORP probe Type 8203 of 120 mm with PG13.5 connection See data sheet Type 8203 ▶ A conductivity probe Type 8221 of 120 mm with PG13.5 connection which is screwed into the PG13.5 thread. See data sheet Type 8221 ▶ 	
	<p>3 A pipe</p>	

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024



Analysis measurement chamber

With one sensor slot for chlorine measurement

Note:

- The special holder is intended for use with a Type 8232 chlorine sensor, see **data sheet Type 8232** ▶ for further information.
- Observe the maximum height of the chlorine sensor (approx. 220 mm without connected cable) when selecting the installation site for the Type 8200 analysis measurement chamber, so that the sensor can be set into the analysis measurement chamber.

A complete chlorine sensor consists of the following components:

Installation example	No.	Description
	<p>1</p> <p>A chlorine sensor Type 8232 (not included in the delivery), see data sheet Type 8232 ▶</p> <ol style="list-style-type: none"> 1. Seal 2. Slide ring 3. Snap ring 	
	<p>2</p> <p>An analysis measurement chamber Type 8200 with nut and seals, which is made of:</p> <ol style="list-style-type: none"> 1. Water outlet, 6 x 8 mm hose connection 2. Float (flow indicator) 3. Knurling for sample 4. Water sample 5. M10 sealing plug 6. Water inlet, 6 x 8 mm hose connection 7. Knurling for flow regulation 8. Drilling for flow switch (optional) 9. Holes for fixing screws 10. Union nut for holding the sensor (to be removed before installing the chlorine sensor, seal and rings, then screwed back in to tighten the sensor) 	

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

With three slots for chlorine, temperature sensors and one other analysis probes

Note:

- The special holder is intended for use with a Type 8232 chlorine sensor, a temperature sensor (see chapter “8.5. Ordering chart accessories” on page 28) and one other analysis probe (pH, ORP Type 8203 or conductivity Type 8221...) with a PG13.5 threaded connection, see **data sheets Type 8232 ▶, Type 8203 ▶ and Type 8221 ▶** for further information.
- Observe the maximum height of the chlorine sensor (approx. 220 mm without connected cable) when selecting the installation site for the Type 8200 analysis measurement chamber, so that the sensor can be set into the analysis measurement chamber.

A complete analysis system consists of the following components:

Installation example	No.	Description
	1	A chlorine sensor Type 8232 (not included in the delivery), see data sheet Type 8232 ▶ 1. Seal 2. Slide ring 3. Snap ring
	2	An analysis measurement chamber Type 8200 with nut and seals, which is made of: 1. Thread for sensor union nut (not shown) 2. Water outlet, 6 x 8 mm hose connection 3. Holes for fixing screws 4. Sealing plug (drain) 5. Sampling tap, 8 x 10 mm hose connection 6. Water inlet, 6 x 8 mm hose connection 7. Knurling for flow regulation 8. Float (flow indicator) 9. Drilling for flow switch (optional) 10. Sealing plug (drain) 11. For temperature sensor (not included in the delivery, see chapter “8.5. Ordering chart accessories” on page 28) or sealing plug 12. Union nut
	3	An analysis probe with a PG13.5 threaded connection (not included in the delivery) or if none a sealing plug

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

With four slots for chlorine, temperature sensors and two other analysis probes

Note:

- The special holder is intended for use with a Type 8232 chlorine sensor, a temperature sensor (see chapter “8.5. Ordering chart accessories” on page 28) and two other analysis probes (pH, ORP Type 8203 or conductivity Type 8221...) with a PG13.5 threaded connection, see **data sheets Type 8232 ▶, Type 8203 ▶ and Type 8221 ▶** for further information.
- Observe the maximum height of the chlorine sensor (approx. 220 mm without connected cable) when selecting the installation site for the Type 8200 analysis measurement chamber, so that the sensor can be set into the analysis measurement chamber.

A complete analysis system consists of the following components:


Installation example	No.	Description
	<p>1</p> <p>A chlorine sensor Type 8232 (not included in the delivery), see data sheet Type 8232 ▶</p> <ol style="list-style-type: none"> 1. Seal 2. Slide ring 3. Snap ring 	
	<p>2</p> <p>An analysis measurement chamber Type 8200 with nut and seals, which is made of:</p> <ol style="list-style-type: none"> 1. Union nut for holding the sensor (to be removed before installing the chlorine sensor, seal and rings, then screwed back in to tighten the sensor) 2. Water outlet, 6x8 mm hose connection 3. Holes for fixing screws 4. Sealing plug (drain) 5. Sampling tap, 8x10 mm hose connection 6. Water inlet, 6x8 mm hose connection 7. Sealing plug (drain) 8. Knurling for flow regulation 9. Float (flow indicator) 10. Drilling for flow switch (optional) 11. For temperature sensor (not included in the delivery, see chapter “8.5. Ordering chart accessories” on page 28) or sealing plug 	
	<p>3</p> <p>Analysis probes with a PG13.5 threaded connection (not included in the delivery) or if none a sealing plug</p>	

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

7. Networking and combination with other Bürkert products

7.1. Combination of general purpose holder with G 2" connection for installation on S020 Bürkert fitting

Example:



7.2. Combination with available Type S020 Insertion fittings DN

Available S020 fittings DN	DN15	DN32 ¹⁾	DN50	DN65	DN100	DN200
T-Fitting	Available					
Welding socket			Available			
Fusion spigot				Available		
Analytical measurement using probe holder G 2" connection for S020	Available ²⁾					


1.) Except fittings with external threads acc. to SMS 1145, weld ends acc. to SMS 3008, BS 4825-1/ASME BPE/DIN 11866 series C or DIN 11850 series 2/DIN 11866 series A/ DIN EN 10357 series A, Clamp acc. to SMS 3017, BS 4825-3/ASME BPE, DIN 32676 series A

2.) Only use plastic fittings with true union process connection in the analysis variant, with nut and solvent/fusion socket according to DIN 8063 (PVC), to DIN 16962 (PP) or to ISO 10931 (PVDF), other materials are available on request.

See **data sheet Type S020** ▶ for more information.

7.3. Combination of general purpose with G 1", solvent connection or hygienic holders


Example:




DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | valide) printed: 17.07.2024

7.4. Combination of the analysis measurement chamber

Example:



DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024



8. Ordering information

8.1. Bürkert eShop



Bürkert eShop – Easy ordering and quick delivery

You want to find your desired Bürkert product or spare part quickly and order directly? Our online shop is available for you 24/7. Sign up and enjoy all the benefits.

[Order online now](#)

8.2. Recommendation regarding product selection

General purpose or hygienic holders for pH/ORP/conductivity measurement for tank or pipe installation

Depending on the Type of measurement to be performed, different components must be ordered in order to select a complete pH, ORP or conductivity meter for tank or pipe installation. The following information is required:

- For pH/ORP measurement
 - **Article no.** of the probe holder **Type 8200**
 - **Article no.** of the pH or ORP probe **Type 8203** (see [data sheet Type 8203](#) ▶)
 - **Article no.** of the Pt1000 temperature probe/liquid earth rod if needed (see chapter [“8.5. Ordering chart accessories” on page 28](#))
 - **Article no.** of the selected Insertion fitting **Type S020** (DN 15...DN 200, see [data sheet Type S020](#) ▶) **only** if probe holder has a G 2" connection or of the selected socket (see chapter [“8.5. Ordering chart accessories” on page 28](#)) **only** if the probes holder has a G 1¼" connection with O-ring position of 28 or 46 mm.
- For conductivity measurement
 - **Article no.** of the probe holder **Type 8200**
 - **Article no.** of the conductivity probe **Type 8221** (see [data sheet Type 8221](#) ▶)
 - **Article no.** of the selected Insertion fitting **Type S020** (DN 15...DN 200, see [data sheet Type S020](#) ▶) **only** if probe holder has a G 2" connection or of the selected socket (see chapter [“8.5. Ordering chart accessories” on page 28](#)) **only** if the probes holder has a G 1¼" connection with O-ring position of 28 or 46 mm.

Analysis measurement chamber


Note:

- A complete analysis measurement system consists of a analysis measurement chamber Type 8200, a chlorine sensor and, depending on the analysis measurement chamber variant, a temperature sensor and one or two analysis probes.
- If a slot is not used, it must be sealed with a sealing plug (see chapter [“8.5. Ordering chart accessories” on page 28](#)).

Different components must be ordered in order to select a complete device. The following information is required:

- **Article no.** of the analysis measurement chamber **Type 8200**
- **Article no.** of the chlorine sensor **Type 8232** (see [data sheet Type 8232](#) ▶)
- **Article no.** of the temperature sensor (see chapter [“8.5. Ordering chart accessories” on page 28](#))
- **Article no.** of the pH or ORP probes Type 8203 (see [data sheet Type 8203](#) ▶) or of the conductivity probe Type 8221 (see [data sheet Type 8221](#) ▶) if needed
- **Article no.** of the flow switch for continuous monitoring of the flow according to the analysis measurement chamber variant (optional, see chapter [“8.5. Ordering chart accessories” on page 28](#))

8.3. Bürkert product filter



Bürkert product filter – Get quickly to the right product

You want to select products comfortably based on your technical requirements? Use the Bürkert product filter and find suitable articles for your application quickly and easily.

[Try out our product filter](#)





8.4. Ordering chart

General purpose or hygienic holders for pH/ORP/conductivity measurement for tank or pipe installation








Process connection	Variant	Material	Boring for Pt1000 temperature probe/ liquid earth rod	Protection rods/tube	Article no.		
General purpose holder							
	G 2" connection for installation on Bürkert Insertion fitting S020	Standard	PVC	No	Yes	429224	
			Stainless steel 316L/1.4404	Yes	Yes	429228	
				PVC	No	Yes	429227
				Stainless steel 316L/1.4404	Yes	Yes	429231
	G 1" connection	Short	PVC	No	No	429220	
			Stainless steel 316L/1.4404	Yes	No	429221	
	Stick connection	Short	PVC	No	No	564236	
			Stainless steel 316L/1.4404	Yes	No	563475	
Hygienic purpose holder							
	G 1 1/4" connection	High = 28	Stainless steel 316L/1.4435	No	Yes	562431	
		High = 46	Stainless steel 316L/1.4435	No	Yes	562432	
	1 1/2" clamp connection (Ø 50.5 mm)	Short immersion depth	Stainless steel 316L/1.4435	No	Yes	558885	
		Long immersion depth	Stainless steel 316L/1.4404	Yes	Yes	429235	
	2" (DN 50/40) connection adapted for GEA Tuchenha-gen VARINLINE process connections	15°	Stainless steel 316L/1.4435	No	Yes	562433	
	Hygienic direct welding connection	Standard	Stainless steel 316L/1.4435	No	No	561728	

DTS 1000141421 EN Version: Z Status: RL (released | freigegeben | validé) printed: 17.07.2024

Analysis measurement chamber

Description	Article no.
Analysis measurement chamber with 1 slot (G 1¼" connection) for a chlorine sensor	569221 
Analysis measurement chamber with 1 slot (G 1¼" connection) for a chlorine sensor, 1 slot (G ½" connection) for a temperature sensor and 1 slot (PG13.5) for an analysis probe, cold water variant	571930 
Analysis measurement chamber with 1 slot (G 1¼" connection) for a chlorine sensor, 1 slot (G ½" connection) for a temperature sensor and 1 slot (PG13.5) for an analysis probe, warm water variant	571931 
Analysis measurement chamber with 1 slot (G 1¼" connection) for a chlorine sensor, 1 slot (G ½" connection) for a temperature sensor and 2 slots (PG13.5) for two analysis probes	571932 

8.5. Ordering chart accessories

Description	Article no.
Temperature probe for general purpose holders G 2", G 1", stick connection and hygienic holders 1½" clamp or DN 50 thread process connection	
Pt1000/earthing pin made of stainless steel 1.4571	427023 
Pt1000/earthing pin made of titanium	560317 
For general purpose holders G 2" connection	
Set with FKM seals	429264 
Set with a green FKM seal and a black EPDM seal	552111 
For hygienic holder G 1¼" connection	
Weld-in socket 15° Type BBS-11 ▶, length: 30 mm for holder G 1¼"	747772 
Weld-in socket 15° Type BBS-11 ▶, length: 46 mm for holder G 1¼"	737260 
For analysis measurement chamber	
Pt100 temperature sensor with 4 m cable for analysis measurement chambers with 3 or 4 sensor slots	571962 
Flow switch for analysis measurement chamber, PNP, 2 m cable (optional)	775261 